TOP AND CONSOLE PARTS

For Models: 3XLER5435HQ0
(Designer White)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: 3XLER5435HQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		LITERAURE PARTS
	LIT3401012	Use & Care Guide
	LIT3394036	Operating Instructions
	LIT3397626	Installation Instructions (Spanish)
	LIT3397627	Installation Instructions (English)
	LIT3406302	Wiring Diagram
2	3396028	Wire Jumper Assembly
3	693995	Screw, Hex Head
4	3950975	Cap, End (L.H.)
5	357572	Clip, Ground
6	357213	Stop, Push−In
8	3397545	Panel, Rear Console
9	3950974	Cap, End (R.H.)
10	349639	Handle & Lint Screen Assembly
11		Cover, Lint Screen
	688150	White
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	388326	Screw, Console
15	3399638	Switch, Temperature
16		Top
	3396022	White
18	3950759	Knob, Control
20	3401688	Harness, Ground
21	3396215	Timer 60 Hz.
29	3390646	Screw, 8−18 x 5/16
31	8283159	Harness, Wiring
39	3395382	Switch, Push−To−Start
48	3406143	Knob, Timer
53	8054298	Bracket, Control
54	3401065	Panel, Control
72	690853	Wire, Ground
81	3406133	Knob, Push To Start

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	72107	Almond
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350956	Almond
	350938	Primer, Gray
	350941	Leveler (Thinner)
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	978883	Almond (Uncut)
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	LIT677818	Dryer

CABINET PARTS

For Models: 3XLER5435HQ0

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: 3XLER5435HQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Washer Head
5	3396795	Cover, Terminal Block
6	3403630	Plug, Strike Hole
7	3396805	Panel, Rear
10	3406104	Switch, Door
11	697773	Screw
12	3404413	Plug, Hinge Hole (4)
15	3394083	Clip, Front Panel
16	3392100	Foot (4)
18	3399585	Cabinet
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21	3403444	Front Panel Assembly
23	685203	Clip, Felt Pad (2)
24	690081	Catch, Door
27	342055	Screw (8)
28	3405514	Hinge & Pin Assembly
29	279318	Terminal, Tinned & Brass (3) (Includes Illus. 42)
33	3403431	Strike, Door
35	3402341	Door, Rear
36	3402335	Door, Front
37	3405184	Handle, Door
38	3406129	Seal & Bearing Assembly
39	694415	Clip,Strain Relief
41	3397659	Block, Terminal
42	279393	Terminal Block Kit For Terminal Block
45	3387258	Cord, Power
51	238088	Hinge, Top (2)
52	690046	Screw, Set
53	691366	Idler & Pulley Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	685064	Pulley, 50 Hz. (Includes Item No. 52)
60	3404162	Clamp, Motor
61	3388235	Switch, Motor
62	685815	Motor Assembly, 50/60 Hz.
63	660658	Clip, Motor (2) 343481 (Alt.) 685441 (Alt.)
64	690236	Wire, Ground
67	3405246	Seal, Door
87	697776	Screw, 10−32 x 1/2 (Grounding)

BULKHEAD PARTS

For Models: 3XLER5435HQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	3977393	Thermostat, Cut−Off
5	90767	Screw, 8 x 3/8
6	3387137	Thermostat, Internal−Bias
8	694511	Thermal Fuse
9	3388703	Washer, Support
10	694089	Wheel, Blower (Includes Illus. No. 19)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3977749	Thermostat, (High Limit) 200°/120F
17	3403586	Element, Heater
18	279457	Wire Kit (For Heater Element Wiring Harness Repair)
19	3394196	Seal, Blower
21	489463	Screw, 8−18 x 5/8
24	347139	Seal, Lint Chute
40	3977358	Drum,Hole Plug
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer Support
47	3359452	Nut, 3/8−16
48	3403491	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST